


VPC-Tip #39 – Text Size on VPC Drawings

Text Size On VPC Drawings

VPC version 4.5 has added a Drawing feature that will enable you to *enlarge or ALL decrease the size of text that is not in a table*. You can still modify table text as in the past.



From inside the VPCCommand Drawing

function, the “A”, and “A” toolbar buttons will increase or decrease the size of text as desired.

This feature applies to all text on the drawing that is not in a table. Each time you “click” on the button, the text will increase or decrease in size as selected.

Massachusetts Sample Project 2004.VPC]

1 Page Prev Page Two Page Zoom In Zoom Out Close

Bar	Schedule	Wch	Thick	Webbck	Depth1	Depth2	Approx. Lgth	Qty	Size	Length	Block	Dist	Stn	Tension	Member	Bolt	
1	5"	3750	1664	1'-0"	2'-9"	8'-11 13/16"	25'-0 3/4"	A	10	3/4"	2 1/4"	5/8"	3	2			
2	5"	3750	1664	1'-0"	2'-9"	8'-11 13/16"	25'-0 3/4"	B	8	3/4"	2"	1/2"	1	3			
3	5"	3750	1664	1'-0"	2'-9"	8'-11 13/16"	25'-0 3/4"										
4	5"	3750	1664	1'-0"	2'-9"	8'-11 13/16"	25'-0 3/4"										
5	5"	3750	1664	1'-0"	2'-9"	8'-11 13/16"	25'-0 3/4"										
6	5"	3750	1664	1'-0"	2'-9"	8'-11 13/16"	25'-0 3/4"										

Before you print your drawing you should click on the “Print Preview” option to verify you will receive the desired results.

